



Instruction Manual

WIFI BATTERY CAMERA



Scan Code Download Onecam APP

Please read it carefully before using the device and keep this handy.

DIRECTORY

Product categories

Technical Parameters

Tips for use

Add Device

TF Card Video

Cloud Storage Video

Device Sharing

AP Hotspot Mode


Device Screen List

Basic-Setting List

FAQ


Product categories

1




Bottom

4



Bottom

5



Bottom


14



Bottom



USB Charging Port



Top


2




Loudspeakers



Loudspeakers



USB Charging Port



Top


2



TF Card Slot

Loudspeakers

Bottom




TF Card Slot

Loudspeakers

USB Charging Port

battery

Bottom



TF Card Slot

Loudspeakers

USB Charging Port

battery

Bottom

3



USB Charging Port

TF Card Slot

Bottom

Technical Parameters:



Resolution: 720X1280 1920X1080
 Viewing angle: 135-165°
 Audio: Built-in speaker & Microphone
 Power Supply: DC 5V
 Motion Detection: PIR Sensor
 Recording method: SD Memory Card/ Cloud Storage
 Power consumption: Standby 200uA, Working 260mA

Video bit rate: adaptive
 Support capacity: Up to 128G
 WiFi Mode: 2.4GHz 802.11n/g/n
 Battery: Rechargeable Battery

Tips for use

- This Camera only supported 2.4G WIFI, not supported 5G WIFI .
- Please fully charge the Camera before using it. The charging time is 6-8 hours.
- Video Camera connection wifi operation guide:
 - After the camera is fully charged, please approach the wifi router within 2M when matching the phone and the doorbell. The location where the camera is installed cannot exceed the wifi coverage by 10 meters.
 - The App cannot detect whether your password is wrong. When entering the wifi password, please make sure that the password is correct, otherwise the phone will not connect to wifi.
 - Router check operation: There are too many clients connected to the router itself, which exceeds the quota limit, resulting in failure to connect, restart the router.
- Register the App with your phone number or email address.
 - Allow "OneCam" Would like to send you Notifications.
 - Allow "OneCam" to use your location.
- Apple phone users and Android phone users-Registration Process:


Step 1: Apple phone users-Allow all permissions of the App



5

Step 2:

- Android phone users-Allow Onecam to take pictures and record video.
- Allow Onecam to access this device's location.
- Allow Onecam to access photos and media on your device.





- Allow Onecam to record audio.
- Allow Onecam to access device information.
- User Agreement and Privacy Policy.




6


- Save username and password.
- Click on- Go to set.
- Open Manage manually:Auto-launch/Secondary launch/Run in background.



- Allow permissions are turned on.
- Allow ignore battery optimizations automatic management.






7





2.Add Device

- Log in to the APP, click the "+" in the device list, and pop up a window to choose "Add intelligently".





8



3.TF Card Video



Click the "Playback" icon to view the video in the TF card (Note: The device needs to be plugged in the TF card, the alarm detection is enabled and the video is recorded before the video file can be found).



9


4.Cloud Storage Video

Click the cloud storage function icon in the device list page,Enter the cloud storage video query and open the purchase page.




5.Device Sharing

Click the "Share" icon to enter the "Share Management", click the "Share" button, your family can click the "+" APP to select "Scan" to share the device code, you can view your shared device.



10




11



6.AP Hotspot Mode


Reset the device, open the APP, click "Add Device" and select "AP Mode" to enter the hotspot connection interface.Click "Next" to enter the mobile phone WIFI selection page, find the WIFI hotspot named "Onecam-xxxxx" to connect, (WiFi password: 123456789).



12




13



14

Basic-setting List

⋮	Setting
📺	Full Screen
HD	HD/SD Switch
🔊	Sound/Silent
🔋	Battery Power Indicator
📷	Screenshot
🗣️	Intercom
📹	Record Video
⏮️	Playback
☁️	Cloud Video
👁️	Night Vision
🔍	Motion Detection
🚨	SOS



Note: The video and screenshot information will be saved in the phone album by default.

15

FAQ

Q: What should I pay attention to before using the product?
A: When the product is paired, ensure that the distance is within 2 meters of the WiFi signal coverage of the router to add network operations. It is recommended to install the device within 10 meters of the router.

Q: What should I do if I cannot receive the verification code during email registration?
A1:Please make sure your email account is entered correctly
A2:Some mail clients will recognize the verification code as spam, please go to the spam inbox to check whether there is a verification code email.

Q: Why are there issues with push delay and wake-up delay?
A1:The product transmits data through a wireless network, and it takes 0-1s to convert and output the data when processing the data, so there will be a 0-1s delay when the product is used. Please use it normally about 5 seconds after the product is successfully connected (operate after the connection is stable).
A2: If the wifi signal is weak or the mobile phone signal is weak, it may also cause offline and disconnection, and push notification delays. Before buying, check the wifi coverage area to ensure sufficient signal to avoid a bad experience.

Q:The device is online and the APP cannot receive push messages?
A1: The mobile phone turns on "automatic management" for the "Onecam"APP and turns on all the permissions and notification functions of the APP.
A2: If you turn off the [Allow Notification] of the APP in the [Notification and Status Bar] of Huawei/Xiaomi mobile phones,there will be no reminder in the notification bar.

16